

ASSEMBLY AND FITTING INSTRUCTIONS



- Remove your cycle stowage system from the box and dispose of all packaging responsibly.
- Lift the tray and telescopic slide combo into your van and dry fit into position. (Before screwing down make sure you have checked clearance for the widest handlebar width that will be placed on the tray).
- Push down the red locking tabs and slowly slide the tray out to full extension on the slides. Once in position you will hear a click.
- Ask a friend to support the front of the tray (or use a support) and screw the telescopic slide brackets into your van floor using your choice of fixings (depending on how your van is built or where you are mounting them).
- Once the slides are secured to the van floor, push the red locking tabs down again and slide the tray back into the fully closed position. When fitted correctly, this system will slide in and out smoothly.
- Your system is now ready to use. If you are using our fork/rear wheel mount combo, simply position them both where your forks/rear wheel will be located on the tray and secure using the supplied M6x40 countersunk bolts to a maximum of 9Nm torque. Simply use your wheel axle to bolt your forks to the fork mount and you're set to go riding!

